

Kangaroo Golfstream™

QUICK START GUIDE



Designed in GREAT BRITAIN

KangarooGolfstream.com

(828) 436-2101

Mon.-Fri. 8-5 ET

GETTING STARTED



From folded position, pull up on handle until latch on center tube snaps into place. To fold caddy, press latch on center tube and push down on the handle.

Handy magnet keeps folded caddy compact and secured. Hold side strut to carry. Magnet will hold your caddy together.



STOP/GO



Place CaddyCell Lithium battery sideways in tray on the chassis. Secure with strap. Plug power connector into port on chassis.

Once battery is plugged in, the Vision Screen will begin to flash and display "Power Off". This signals Golfstream is idle and not "Power On" yet.



To begin operating, press orange button on handle. After pressing button, Vision Screen displays "Power On".



Rotate dial on handle to your desired speed setting. Speeds start at 0.5 and go up to 9.5 in increments of 0.5.

A second push of orange button causes cart to stop, with flashing "Power Off" again on Vision Screen.

When finished playing your round, unplug battery to completely turn off your Golfstream.

THINGS TO KNOW



- To secure your golf bag, hook at the top and bottom with elastic bag straps. The black fabric separator on the strap allows you to ensure the strap is the right distance apart.

Battery must be placed in battery tray sideways to snap in place correctly.

- Always remove battery from caddy before charging.

- Be careful to protect breakable Vision Screen. When loading your caddy into the trunk of a car be sure nothing falls or rubs against the screen.



- It doesn't hurt the Golfstream to push it forward while powered off. But **DO NOT** pull the caddy backward, **EVEN WHEN POWER IS OFF** because it will damage the motor and drive train gears.



- To put caddy in free-wheeling mode, push release button on outside of wheel. Slide wheel outward slightly on the axle. Release button to lock wheel axle's outer groove.



Magnet located on chassis will keep caddy from unfolding.



- To carry your Golfstream properly, grasp it from a SIDE strut when folded flat.



Each Golfstream has a unique serial number, located behind the center tube below the hinge.

Your caddie is warranted for 12 months from purchase date, to the original purchaser in USA or Canada, for defects in manufacture. Ordinary wear & tear from use on the golf course or in transport isn't covered, and

damage due to misuse or abuse isn't covered by warranty. Kangaroo reserves right to require return for inspection to its North Carolina facility, at claimant's expense, packed carefully using the original shipping carton. All claims require serial number as well as name of original purchaser.

CaddyCell battery and charger are separately warrantied.